


ZF RSS with Pad Wear Sensor Part Numbers

Trailer Roll Stability Support

Connection	Application	Part Number	Detail
N/A	 <p>RSSplus™ ECU</p>	480 107 001 0	4S/2M- 2S/2M
Power Port	 <p>Power Cable</p>	449 351 010 0 449 351 047 0	1 M 4.7 M
Sensor Ports (C,D,E,F)	 <p>Sensor Extension Cable</p>	449 723 018 0 449 723 030 0 449 723 051 0 449 723 120 0 449 723 170 0	1.8 M 3 M 5.1 M 12 M 17 M
GIO 2	 <p>Brake Pad Wear Sensor Cable</p>	449 816 013 0 449 816 030 0	1.3 M 3 M
Brake Pad Wear Sensor Cable	 <p>Brake Pad Wear Indicator</p>	441 039 824 2	N/A
Brake Pad Wear Sensor Cable	 <p>Connector Socket</p>	441 902 312 0	N/A

